§ 1.2

True airspeed means the airspeed of an aircraft relative to undisturbed air. True airspeed is equal to equivalent airspeed multiplied by $(\rho 0/\rho)^{1/2}$.

Tune:

- (1) As used with respect to the certification, ratings, privileges, and limitations of airmen, means a specific make and basic model of aircraft, including modifications thereto that do not change its handling or flight characteristics. Examples include: DC-7, 1049, and F-27; and
- (2) As used with respect to the certification of aircraft, means those aircraft which are similar in design. Examples include: DC-7 and DC-7C; 1049G and 1049H; and F-27 and F-27F.
- (3) As used with respect to the certification of aircraft engines means those engines which are similar in design. For example, JT8D and JT8D-7 are engines of the same type, and JT9D-3A and JT9D-7 are engines of the same type.

United States, in a geographical sense, means (1) the States, the District of Columbia, Puerto Rico, and the possessions, including the territorial waters, and (2) the airspace of those areas.

United States air carrier means a citizen of the United States who undertakes directly by lease, or other arrangement, to engage in air transportation.

Unmanned aircraft means an aircraft operated without the possibility of direct human intervention from within or on the aircraft.

Unmanned aircraft system means an unmanned aircraft and its associated elements (including communication links and the components that control the unmanned aircraft) that are required for the safe and efficient operation of the unmanned aircraft in the airspace of the United States.

VFR over-the-top, with respect to the operation of aircraft, means the operation of an aircraft over-the-top under VFR when it is not being operated on an IFR flight plan.

Warning area. A warning area is airspace of defined dimensions, extending from 3 nautical miles outward from the coast of the United States, that contains activity that may be hazardous to nonparticipating aircraft. The purpose of such warning areas is to warn

nonparticipating pilots of the potential danger. A warning area may be located over domestic or international waters or both.

Weight-shift-control aircraft means a powered aircraft with a framed pivoting wing and a fuselage controllable only in pitch and roll by the pilot's ability to change the aircraft's center of gravity with respect to the wing. Flight control of the aircraft depends on the wing's ability to flexibly deform rather than the use of control surfaces.

Winglet or tip fin means an out-ofplane surface extending from a lifting surface. The surface may or may not have control surfaces.

[Doc. No. 1150, 27 FR 4588, May 15, 1962]

EDITORIAL NOTE: For FEDERAL REGISTER citations affecting §1.1, see the List of CFR Sections Affected, which appears in the Finding Aids section of the printed volume and at www.govinfo.gov.

§1.2 Abbreviations and symbols.

In Subchapters A through K of this chapter:

AFM means airplane flight manual.

AGL means above ground level.

ALS means approach light system. APU means auxiliary power unit.

ASR means airport surveillance

ATC means air traffic control.

ATS means Air Traffic Service.

CAMP means continuous airworthiness maintenance program.

CAS means calibrated airspeed.

CAT II means Category II.

CMP means configuration, maintenance, and procedures.

DH means decision height.

 $\it DME$ means distance measuring equipment compatible with TACAN.

EAS means equivalent airspeed.

EFVS means enhanced flight vision system.

Equi-Time Point means a point on the route of flight where the flight time, considering wind, to each of two selected airports is equal.

ETOPS means extended operations.

EWIS, as defined by §25.1701 of this chapter, means electrical wiring interconnection system.

 ${\it FAA}$ means Federal Aviation Administration.

FFS means full flight simulator.
FM means fan marker.

FSTD means flight simulation training device.

FTD means flight training device.

GS means glide slope.

 $\it HIRL$ means high-intensity runway light system.

IAS means indicated airspeed.

ICAO means International Civil Aviation Organization.

IFR means instrument flight rules.

IFSD means in-flight shutdown.

ILS means instrument landing system.

IM means ILS inner marker.

INT means intersection.

LDA means localizer-type directional aid.

 $\it LFR$ means low-frequency radio range.

LMM means compass locator at middle marker.

LOC means ILS localizer.

LOM means compass locator at outer marker.

M means mach number.

MAA means maximum authorized IFR altitude.

MALS means medium intensity approach light system.

MALSR means medium intensity approach light system with runway alignment indicator lights.

MCA means minimum crossing altitude.

MDA means minimum descent altitude.

MEA means minimum en route IFR altitude.

MEL means minimum equipment list.

MM means ILS middle marker.

MOCA means minimum obstruction clearance altitude.

MRA means minimum reception altitude.

MSL means mean sea level.

NDB (ADF) means nondirectional beacon (automatic direction finder).

NM means nautical mile.

NOPAC means North Pacific area of operation.

NOPT means no procedure turn required.

OEI means one engine inoperative.

OM means ILS outer marker.

OPSPECS means operations specifications.

 $\it PACOTS$ means Pacific Organized Track System.

PAR means precision approach radar. PMA means parts manufacturer approval.

POC means portable oxygen concentrator.

PTRS means Performance Tracking and Reporting System.

RAIL means runway alignment indicator light system.

RBN means radio beacon.

RCLM means runway centerline marking.

RCLS means runway centerline light system.

REIL means runway end identification lights.

RFFS means rescue and firefighting services.

RNAV means area navigation.

RR means low or medium frequency radio range station.

RVR means runway visual range as measured in the touchdown zone area.

SALS means short approach light system.

SATCOM means satellite communications.

SSALS means simplified short approach light system.

SSALSR means simplified short approach light system with runway alignment indicator lights.

TACAN means ultra-high frequency tactical air navigational aid.

TAS means true airspeed.

TCAS means a traffic alert and collision avoidance system.

TDZL means touchdown zone lights.

TSO means technical standard order.

TVOR means very high frequency terminal omnirange station.

 V_A means design maneuvering speed.

 V_B means design speed for maximum gust intensity.

 V_C means design cruising speed.

 V_D means design diving speed.

 V_{DF}/M_{DF} means demonstrated flight diving speed.

 V_{EF} means the speed at which the critical engine is assumed to fail during takeoff.

 V_F means design flap speed.

 V_{FC}/M_{FC} means maximum speed for stability characteristics.

 V_{FE} means maximum flap extended speed.

 V_{FTO} means final takeoff speed.

§ 1.3

 V_H means maximum speed in level flight with maximum continuous power.

 V_{LE} means maximum landing gear extended speed.

 V_{LO} means maximum landing gear operating speed.

 V_{LOF} means lift-off speed.

 V_{MC} means minimum control speed with the critical engine inoperative.

 V_{MO}/M_{MO} means maximum operating limit speed.

 V_{MU} means minimum unstick speed. V_{NE} means never-exceed speed.

 V_{NO} means maximum structural cruising speed.

 V_R means rotation speed.

 V_{REF} means reference landing speed. V_S means the stalling speed or the minimum steady flight speed at which the airplane is controllable.

 V_{50} means the stalling speed or the minimum steady flight speed in the landing configuration.

 V_{S1} means the stalling speed or the minimum steady flight speed obtained in a specific configuration.

 V_{SR} means reference stall speed.

 V_{SRO} means reference stall speed in the landing configuration.

 V_{SR1} means reference stall speed in a specific configuration.

 V_{SW} means speed at which onset of natural or artificial stall warning occurs.

 V_{TOSS} means takeoff safety speed for Category A rotorcraft.

 V_X means speed for best angle of climb.

 $V_{\it Y}$ means speed for best rate of climb.

 V_I means the maximum speed in the takeoff at which the pilot must take the first action (e.g., apply brakes, reduce thrust, deploy speed brakes) to stop the airplane within the accelerate-stop distance. V_I also means the minimum speed in the takeoff, following a failure of the critical engine at $V_{\rm EF}$, at which the pilot can continue the takeoff and achieve the required height above the takeoff surface within the takeoff distance.

 V_2 means takeoff safety speed.

 V_{2min} means minimum takeoff safety speed.

VFR means visual flight rules.

VGSI means visual glide slope indicator.

VHF means very high frequency.

VOR means very high frequency omnirange station.

 $\ensuremath{\mathit{VORTAC}}$ means collocated VOR and TACAN.

[Doc. No. 1150, 27 FR 4590, May 15, 1962]

EDITORIAL NOTE: For FEDERAL REGISTER citations affecting §1.2, see the List of CFR Sections Affected, which appears in the Finding Aids section of the printed volume and at www.govinfo.gov.

§ 1.3 Rules of construction.

- (a) In Subchapters A through K of this chapter, unless the context requires otherwise:
- (1) Words importing the singular include the plural;
- (2) Words importing the plural include the singular; and
- (3) Words importing the masculine gender include the feminine.
- (b) In Subchapters A through K of this chapter, the word:
- (1) Shall is used in an imperative sense:
- (2) May is used in a permissive sense to state authority or permission to do the act prescribed, and the words "no person may * * *" or "a person may not * * *" mean that no person is required, authorized, or permitted to do the act prescribed; and
- (3) *Includes* means "includes but is not limited to".

[Doc. No. 1150, 27 FR 4590, May 15, 1962, as amended by Amdt. 1–10, 31 FR 5055, Mar. 29, 1966]

PART 3—GENERAL REQUIREMENTS

Subpart A—General Requirements Concerning Type Certificated Products or Products, Parts, Appliances, or Materials That May Be Used on Type-Certificated Products

Sec

3.1 Applicability.

3.5 Statements about products, parts, appliances and materials.

Subpart B—Security Threat Disqualification

- 3.200 Effect of Transportation Security Administration notification on a certificate or any part of a certificate held by an individual.
- 3.205 Effect of Transportation Security Administration notification on applications